

Combining nano-DIC and ACOM TEM to study the ductility enhancement of aluminium films by grain boundary sliding

Paul Baral^{1,2}, Ankush Kashiwar^{1,3}, Michaël Coulombier¹, Laurent Delannay¹, Khalid Hoummada⁴, Jean-Pierre Raskin⁵, Hosni Idrissi^{1,3} and Thomas Pardoën^{1,6}

¹ Institute of Mechanics, Materials and Civil Engineering (IMMC), UCLouvain, B-1348, Louvain-la-Neuve, Belgium

² Mines Saint Etienne, Univ. Lyon, CNRS UMR 5307 LGF, 42023 Saint Etienne, France

³ EMAT, University of Antwerp, Groenenborgerlaan 171, B-2020, Antwerp, Belgium

⁴ IM2NP, Aix Marseille Univ, CNRS UMR 7334, 13397 Marseille, France

⁵ Institute of Information and Communication Technologies (iCTEAM), UCLouvain, B-1348, Louvain-la-Neuve, Belgium

⁶ WEL Research Institute, B-1300, Wavre, Belgium

(thomas.pardoën@uclouvain.be)

S13 Experimental mechanics

Keywords: nano-DIC, ACOM TEM, freestanding film, aluminium, grain boundary sliding.

The viscoplastic response of metallic nano-crystalline films has been widely studied in the literature by means of nanomechanical testing, such as with in situ TEM experiments [1], [2] or dedicated on chip test methods [3]. The enhancement of ductility (as compared to large grain samples) has been attributed to different mechanisms, including grain boundary sliding, grain growth or kinematic hardening due to dislocation pile up [2], [4]. However, observations of the polycrystal deformation are challenging due to highly refined grain sizes.

The correlative methodology developed in this work allows probing the relationships between the microstructural changes and the total strain field, at a scale never resolved before – i.e. sample size of 2.5 x 25 µm and strain field resolution of 50 nm. The aluminium films deposited by sputtering (210 nm thickness) are mechanically loaded with an on chip method [3] and then observed after deformation in the transmission electron microscope (TEM). Nanoscale digital image correlation (nano-DIC) reveals multiple necking regions appearing at low plastic strains and further spreading along the sample gauge without leading to critical failure. Automated crystal orientation mapping (ACOM TEM) indicates that strain localization bands correspond to grain boundaries (GB) and that the global texture remains unchanged.

The local shear amplitude achieved by such GB sliding correlates, to some extent, with the GB character. The complementary results obtained by both techniques shed some new light on the link between GB mediated plasticity and enhanced macroscopic ductility.

REFERENCES

- [1] H. Idrissi *et al.*, *Applied Physics Letters*, vol. 104, no. 10, p. 101903, 2014.
- [2] J. P. Liebig *et al.*, *Acta Materialia*, vol. 215, p. 117079, 2021.
- [3] S. Gravier *et al.*, *J. Microelectromech. Syst.*, vol. 18, no. 3, pp. 555–569, 2009.
- [4] F. Momprou *et al.*, *Acta Materialia*, vol. 61, no. 1, pp. 205–216, 2013.